



*Introducing
The N' Album by Natico*



253 West 35th Street, 2nd Floor, New York, NY 10001
Tel: 212.685.5307 - Fax: 212.779.8931 - sales@natico.com - www.natico.com

in the office



on your home wall unit






in your living room



on your nightstand




N'Album Layout Guide




DECK
16'
A-A

A-A



N'Album Remote



1. **POWER:** Power on/off
2. **Brightness/Darkness:** Turn to Darkness for screen saving.
3. **16:9/4:3 display:** Display picture in proportion of 16:9 or 4:3.
4. **PHOTO/ TIME :** Convert to time mode or exit time mode .
5. **ENTER:** Yes/Select function.
6. **ESC:** Exit/Stop Slide show/Stop Video/No.
7. **ROTATE:** Turn picture 90° clockwise.
8. **ZOOM:** Zoom in/out picture.
9. **SETTING:** Setup Menu.
10. **SLIDE:** Picture Slide show.
11. **DELETE:** Delete selected picture.
12. **PAGE UP:** Go to previous page.
13. **PAGE DOWN:** Go to next page.
14. **Up:** Move highlight up/Yes to quit OSD setting.
15. **Down:** Move highlight down/Yes to quit OSD setting.
16. **Right:** Move highlight right/Next picture/Alarm Snooze.
17. **Left:** Move highlight left/Previous picture/Alarm Dismiss.